

**Body Silk
Formulation J1/29A and B**

Phase	Ingredients	J1/29A %	J1/29B %
A	Deionized Water	45.47	62.97
A	Ultrez® 10	0.13	0.13
A	Glycerin	3.00	3.00
B			
B	Stearic Acid	0.5	0.50
B	Cetyl Alcohol	0.4	0.40
B	JEECHEM® GMS-165	1.50	1.50
B	JEECHEM® ISP	7.00	7.00
B	JEECHEM® EGMS	1.00	1.00
C			
C	JEESILC® 3D5	35.00	17.50
D			
D	Triethanolamine 99%	1.00	1.00
D	Water	2.00	2.00
E			
E	JEECIDE® GII	1.00	1.00
E	Vitamin E Acetate	0.50	0.50
E	JEECHEM® FS-102	1.00	1.00
E	Fragrance	0.50	0.50
	D&C Red 40	qs	-
	D&C Violet 2	-	qs

Procedure:

- 1.) Add D.I. Water and Glycerin and sprinkle in Ultrez® 10 under propeller mixing. Heat Phase A to 70°C.
- 2.) Combine Phase B ingredients and heat to 75°C.
- 3.) When phases are at temperature, insert homomixer into Phase A and add Phase B.
- 4.) Cool batch to 55-60°C and add Phase C and homogenize.
- 5.) When uniform, change to sweep and add pre-mix Phase D slowly.
- 6.) Pre-mix Phase E in a side vessel.
- 7.) Cool batch to 45°C and add Phase E.
- 8.) Add in dyes

You Can Count On Us!

This information is furnished without warranty, expressed or implied, except that it is accurate to the best knowledge of JEEN International Corporation. The data on this sheet relates only to the specific material designated herein.