



16 Law Drive
 Fairfield, NJ 07004
 Tel #: 973-439-1401
 Fax #: 973-439-1402
 info@jeen.com
 www.jeen.com

Mask Dot NMF

<u>Code</u>	<u>Application</u>	<u>Body Parts</u>	<u>Form</u>	<u>Appearance</u>	<u>Emulsion Type</u>
J43-28	Skin Care	Face,Hand/Foot	Liquid	Peach	Solution

Just Drop the sealed mask dot into the pre-measured power packed solution of skin beneficial ingredients and watch the mask develop into a 10 minute vacation on the spot. Formulated and balanced to restore skin's NMF, this mask refreshes, rejuvenates, and replenishes your skin in less than 10 minutes. It's a pocket vacation.

Trade Name				
Phase	INCI Name	%	Vendor	Highlight Jeen Ingredients
A	WATER Deionized Water	58.210	Jeen	
A	ALOE VERA GEL DECOLORIZED 10X Aloe Barbadensis Leaf Juice	2.0000	Jeen	
A	BP - COCONUT WATER Coconut Water	10.0000	BotanicalsPlus	
A	Cellulose Gum 0.5% Sol. Cellulose Gum 0.5% Sol.	10.0000		
A	BP-BOTANIDEW NMF Water, Citrullus Lanatus (Watermelon) Fruit Extract, Chenopodium Quinoa Extract, Urea, Sucrose, Glycerin, Sodium Lactate, Sodium PCA	15.0000	BotanicalsPlus	BP-BotaniDew™ NMF is designed to provide immediate to long lasting hydration of the skin by restoring the key elements of skin's NMF.
B	GLYCERIN 99.5% USP Glycerin	3.0000	Jeen	
B	SOY LECITHIN Soy Lecithin	0.5000		
B	Fragrance	0.2400		
B	JEECID® PHENOXY Phenoxyethanol	1.0000	Jeen	Jeecide Phenoxy is a Globally Approved Preservative for Personal Care Applications. It is a clear, colorless, oily liquid with a slight aromatic odor, it is effective against both Gram-negative and Gram-positive bacteria, and against yeast, and mold.
B	RED #27 (0.1% sol, in PG) Red #27 (0.1% Sol, In Pg)	0.0500		
		100.0000	%	

Procedure		Product Specifications	
1	PHASE A In main beaker, add Phase A ingredients one at a time and mix until completely dissolved and uniform.	pH	5.25 - 5.75
2	PHASE B In separate beaker, pre-mix Phase B ingredients one at a time and mix until completely dissolved and uniform.	Viscosity LV SP61 @ 100 RPM. @ 1min.	13.0 - 14.0 cPs
3	Add Phase B to Phase A.		
4	Adjust pH to 5.25 - 5.75.		

Innovation you can feel

This information is furnished without warranty, expressed or implied, except that it is accurate to the best knowledge of JEEN International Corporation. The data on this sheet relates only to the specific material designated herein